


VCC VCC P52 P53 P41 P42 P43 GND GND



www.STCAI.com P32 INT0

www.STCAI.com P33 INT1

擎天柱2

Ai8051U-LQFP48
转89C52-DIP40

Ai8H2K12U
-45MHz-S0P8
自动停电上电


POWER

V1.0
20241028

Ai8051U转 88 89C52-DIP40 2 核心板

擎天柱2

www.STCAI.com

分銷商電話:  R55  6
0513-55012928、89896509

R10



R7

6ND 6ND P43 P42 P41 P53 P52 VCC VCC

